

Sunbeam **Salon Finish**
Ionic Hairdryer

INSTRUCTION BOOKLET.



PLEASE READ THIS BOOK THOROUGHLY AND RETAIN FOR FUTURE REFERENCE.

HD2850

Sunbeam's Safety Precautions.

SAFETY PRECAUTIONS FOR YOUR IONIC HAIRDRYER.

- This hairdryer must not come into contact with water or any other liquid.
- Always switch off your hairdryer at the power outlet and remove the plug when not in use.
- Do not wind the cord around the hairdryer when not in use.
- Do not use or store your hairdryer near tubs, basins, baths or other vessels which contain water.
- When the hairdryer is used in a bathroom, unplug it after use since the proximity of water presents a hazard, even when the unit is switched off.

SAFETY PRECAUTIONS FOR ALL ELECTRICAL APPLIANCES

Sunbeam are very safety conscious when designing and manufacturing consumer products, but it is essential that the product user also exercise care when using an electrical appliance. Listed below are precautions which are essential for the safe use of an electrical appliance:

- Read carefully and save all the instructions provided with an appliance.
- Always turn the power off at the power outlet before you remove a plug. Remove by grasping the plug - do not pull on the cord.
- Turn the power off and remove the plug when the appliance is not in use and before cleaning.
- Do not use your appliance with an extension cord unless this cord has been checked and tested by your electricity supplier or qualified technician.
- Always use your appliance from a power outlet of the voltage (A.C. only) marked on the underside of the appliance.
- Close supervision is necessary when your appliance is being used near children or infirm persons.
- Never leave an appliance unattended while in use.
- Young children or infirm persons should be supervised to ensure that they do not play with the appliance.
- Do not use an appliance for any purpose other than its intended use.
- Do not place an appliance on or near a hot gas flame, electric element or in a heated oven. Do not place on top of any other appliance.
- Do not let the power cord of an appliance hang over the edge of a table or bench top or touch any hot surface.
- Do not immerse in water.
- For safety reasons and to avoid maintenance by unskilled persons, some appliances are 'sealed' using tamperproof means as specified by S.A.A. (Standards Association of Australia). Such appliances should always be returned to the nearest Service Centre for adjustment or repair if required.
- Do not operate any electrical appliance with a damaged cord or after the appliance has been dropped or damaged in any manner; If damage is suspected, return the appliance to the nearest Service Centre for examination, repair or adjustment. As a service to Customers, Service Centres will carry out a free check on your appliance to ensure it is electrically safe.
- For additional protection Sunbeam recommend the use of a residual current device (RCD) with a tripping current not exceeding 30mA in the electrical circuit supplying the power outlet in use.

If you have any concerns regarding the performance and use of your appliance, please ring our Toll Free number (Australia only) 1800 025 059. New Zealand – contact the Sunbeam Office in Auckland.

Ensure the above safety precautions are understood.

تأكد من تفهم احتياطات السلامة المذكورة اعلاه

請務必理解上述的安全預防措施。

Assurez-vous que les précautions ci-dessus relatives à la sécurité sont bien comprises

Versichern Sie sich daß die obenstehenden Sicherheitsmaßnahmen Verstanden werden

Βεβαιώστε πως οι παραπάνω προφυλάξεις ασφαλείας γίνονται κατανοητές

Pastikan bahwa tindakan-tindakan keselamatan seperti di atas dimengerti anda

Accertatevi che le suddette norme di sicurezza siano comprese a dovere

上記の注意事項をよくお読みになり、安全を御確認ください

Уверете се дека погоре споменатите мерки на претпазливост се добро разбрани

Asegúrese de que las precauciones de seguridad precedentes sean bien comprendidas


کاری یکنید کہ احتیاطهای بالا حتماً درک بشوند

ต้องแน่ใจว่า ข้อควรระวังเรื่องความปลอดภัยข้างต้นเป็นที่เข้าใจกันดี

Yukarda belirtilen güvenlik önlemlerinin anlaşıldığından emin olunuz

Xin kiểm chắc rằng những biện pháp làm an toàn kể trên được hiểu rõ

Features of your Ionic Hairdryer.



Ion Generator.

The built-in ion generator produces a constant stream of negatively charged ions that condition the hair as it dries. The ions reduce the size of water droplets in the hair, thus reducing drying time and the resulting heat damage. The ions help to smooth the cuticle layer of the hair shaft, leaving hair healthier, shinier and more manageable.

Turbo Boost Button.

Pressing the Turbo boost button temporarily increases the fan speed to generate greater airflow. This increased airflow reduces drying time, and thus reduces the risk of heat damage.

1800 Watt.

Provides fast drying power and high performance.

Cool Shot Button.

Instantly produces a burst of cool air for setting your style in place.

Detachable Concentrator.

Ideal for spot drying and controlled styling.

Setting Switch.

2 heat / speed settings for controlled styling or fast drying.

Hang-Up Loop.

For the convenient and neat storage of your hairdryer.

Using your Ionic Hairdryer.

Before using your hairdryer.

Squeeze excess moisture from your hair and towel dry. Comb hair free of all tangles with a wide tooth comb.

Using your hairdryer.

1. Insert the plug into a 230-240V power outlet and turn the power on.
2. Select the desired heat/speed setting - 1 for controlled styling and finishing, or 2 for all over drying.
3. Using your fingers or a brush, style your hair as usual until dry.
4. To set your style, finish with a burst of cool air from the cool shot. To activate the cool shot, press the cool shot button and hold for the desired length of time.

Using the Turbo Boost Button.

Pressing the Turbo Boost button increases the fan speed to generate more airflow for faster drying. **Do not use the Turbo Boost button for longer than 3 minutes at a time.**

The Ionic feature

The built-in ion generator automatically produces a constant stream of negative ions whenever your hairdryer is in use.

Care and Cleaning.

Turn your hairdryer off after use. Always turn your hairdryer off and remove the plug from the power outlet before cleaning.

Do not immerse your hairdryer in water or any other liquid.

To clean the exterior of your hairdryer, simply wipe over with a damp cloth and wipe dry.

To clean the filter.

Detach the rear cover by gripping it at the sides, and pulling firmly.

Remove any hair and fluff from inside the rear cover and on the rear of the hairdryer. Replace the rear cover by pushing it back into position.

Clean the rear cover regularly to ensure the cleanliness of internal components is maintained to maximise the long life performance of your hairdryer.

Do not wind the power cord around the hairdryer, as this may cause strain and damage the wiring.

Sunbeam is a registered trademark. Made in China. Due to minor changes in design or otherwise, the product may differ from the one shown in this leaflet. Approved by the appropriate Electrical Regulatory Authorities. Backed by Sunbeam's 2 Year Replacement Guarantee and National Service Network.

© Copyright. SUNBEAM CORPORATION LIMITED 2002. (INCORPORATED IN N.S.W.) A.C.N. 000 006 771

For more information or advice on this or any other Sunbeam appliance, visit www.sunbeam.com.au or contact the Sunbeam Consumer Service Line.

Australia 1800 025 059
New Zealand (09) 912 0747.

Free Manuals Download Website

<http://myh66.com>

<http://usermanuals.us>

<http://www.somanuals.com>

<http://www.4manuals.cc>

<http://www.manual-lib.com>

<http://www.404manual.com>

<http://www.luxmanual.com>

<http://aubethermostatmanual.com>

Golf course search by state

<http://golfingnear.com>

Email search by domain

<http://emailbydomain.com>

Auto manuals search

<http://auto.somanuals.com>

TV manuals search

<http://tv.somanuals.com>